# Function and operation
DL04v2

1. Initialization
There is no initial password. Directly press " ***#** " to enter the smart lock operating system.

2. System Setting

(1). User information setting(Pls verifyd admin if setted after pressing "*** #**")

Press "***#**" to enter the system	→ press "**1**" to access "New User"	→ Enter "User Num" then press "#" (Users 1-5 are administrator users)

Add Fingerprint: Press the fingerprint scanner repeatedly 5 times. Setup Successful.	**Add Password:** Enter a 6-8 digit password twice, setup is successful.	**Add IC Card:** the card near the card sensing area. Setup Successful.	← Press "**1**" to access "REG Key"

Add Face: Face the camera and scan by moving your face ,the setup is successful.	← Press "**2**" to access "Enrol On Face"

Add palm vein: Place your palm directly in front of the camera. The addition is successful.	← Press "**3**" to access "Enrol On Paln"

Add REG Hijack: Fingerprint, password,and card can be set.	← Press "**4**" to access "REG Hijack"

(2). Delete User

Press "***#**" to enter the system	→ press "**2**" to access "Delete User"	→ Enter "User Num" then press "#"

(3). Wifi Set

Press "***#**" to enter the system	→ press "**3**" to access "Wifi Set"	→ 1. Configure WiFi → Starting net work
		→ 2. Delet WiFi

(4). System Set

Press "***#**" to enter the system	→ 1. Time&Date	
↓	→ 2. Volume	→ 1. Volume + 2. Volume -
press "**4**" to access "System Set"	→ 3. Verify Mode	→ 1. Single Verify 2. Double Verify
	→ 4. Passagge Mode	→ 1. Passage Disable 2. Passage Enable
	→ 5. Tanper Set	→ 1. Tanper Enable 2. Tanper Disable
	→ 6. PIR Set	→ 1. PIR Enable 2. PIR Disable

（5）．Record

| Press "***#**" to enter the system | → | press "**5**" to access " Record" |

（6）．Factory Reset

| Press "***#**" to enter the system | → | press "**6**" to access " Factory Reset" | → | Yes or No |

3. Installation Setting(Pls verifyd admin if setted after pressing "*** #**")

| Press "**1#**" to enter the system |
| enter admin information |

- 1. Direction (door opening) → 1. Set left 2.Set right
- 2. Inverse → 1. Not push 2.Push
- 3. Anto Lock → 1.Auto Enable 2.Auto Disable
- 4. Threshold → 3~30 S
- 5. Inverse → 100~300 mS
- 6. Torque → 1. Low 2.Medium 3.High
- 6. PIR Set → 1. Wave 2.Medium 3..Long

4. Language Setting(Pls verifyd admin if setted)

Press "**1111#**"——Chinese
Press "**1112#**"——English
Press "**1113#**"——Indonesian
Press "**1114#**"——Russian
Press "**1115#**"——Vietnamese
Press "**1116#**"——Arabic

Press "**1117#**"——Spanish
Press "**1118#**"——Portuguese
Press "**1119#**"——Thai
Press "**1120#**"——Turkish
Press "**1121#**"——Kazakh
Press "**1122#**"——Uzbek

Press "**1123#**"——Kyrgyz
Press "**1124#**"——Hebrew
Press "**1125#**"—— ∃ Language
Press "**1126#**"——Korean
Press "**1127#**"——French
Press "**1128#**"——German
Press "**1129#**"——Malay

Tuya APP Installation

1. Get the Smart life APP
Please open your camera, scan below QR code or search "Tuya" in APP store to install.

Smart life APP

2. User Registration
After installing the Smart life app, you need to create a new account

3. Adding device as below

(1) In the lock system, press "*#", then press 3 to enter "WiFi Set", and press 1 to enter "Configure WiFi".

(2) In the Tuya APP, select the lock (WiFi), fill in the WiFi information(Choose 2.4GHz WiFi), confirm that the lock is flashing,


(1)

(2)

(3)

(3) select "EZ Mode", and wait for the connection to succeed.

(4)

(5)

(6)

⚠ **Precautions**

General Precautions

1. **Avoid Exposure to Moisture:**
The lock is not waterproof. Do not expose it to rain or high humidity, as it may damage electronic components.

2. **Prevent Direct Sunlight:**
Prolonged exposure to sunlight may cause overheating, discoloration, or reduced performance.

3. **Temperature Range:**
Operates between -20°C to 60°C . Avoid installation in areas with extreme temperatures or sudden changes.

4.**Handle with Care:**
Do not drop, hit, or apply excessive force to the lock to prevent damage.

5.Do Not Modify:
Unauthorized disassembly or modification may void the warranty and compromise safety.

After Installation Instructions:

1.**Emergency Mechanical Key:**
Keep the emergency mechanical key in an accessible outdoor location, such as in your car, on your person, at your office, or with family or friends, for use in case of emergencies.

2.**Emergency Power Supply Port:**
If you forget to replace the battery and cannot enter the house, most smart fingerprint locks have an emergency power supply port (TYPE-C) at the bottom. You can use a power bank for temporary power to unlock the door.

3.**Battery Selection:**
For smart locks powered by a lithium battery, regularly check the battery level and charge it promptly. Avoid using fast chargers to extend battery life.

4.**Information Registration:**
Immediately after installation, set up fingerprint, facial recognition, password, or other credentials. It is recommended to register at least two fingerprints from both the left and right hands. Record the administrator password separately to manage access credentials or set temporary access codes.

5.**Fingerprint Unlocking:**
If a fingerprint fails to unlock twice consecutively, consider replacing the registered fingerprint to avoid triggering the error-protection lockout.

6.**Others:**
If people pass by frequently or there is frequent flashing of lights, it is recommended to disable human body detection to prevent rapid battery consumption.